

Basic Dice Bag Tutorial



Supplies needed:


- Scissors capable of cutting two layers of fabric
- Straight pins
- 1 large safety pin (2" or larger is ideal, but you can work with what you have)
- A mode of sewing (I'm using a sewing machine but if you don't have a machine, this can be sewn by hand with a needle it'll just take longer)
- A seam ripper is always helpful

Materials:

- A scrap of fabric, you can use whatever size you've got laying around, but probably want it to be at least 6" square.
- A length of ribbon or string (the size of ribbon is variable, use whatever is proportional to the size of your bag).
- Thread

Sewing instructions

- Fold your fabric in half with right sides facing. Pin it in place so your fabric doesn't shift.
- Sew together two sides of the rectangle.
- Make a double fold hem on the unsewn side: Fold about 1/4" hem on one side of your rectangle and pin it. Sew a single stitch line to secure it. Fold again 1/4" or 1/2" hem, pin it, Sew a single stitch line near the bottom of the hem leaving a gap around the side seam so that you have a space to lead your drawstring through.



- Cut a length of ribbon that is longer than the opening of the bag.
- Secure a safety pin to one end of the ribbon. Push the safety pin into the opening in your hem and use the safety pin to draw the ribbon through the hem.
- Tie the end of the ribbon to secure it.
- Cut off any loose ends.

Free Soft Wear

This tutorial is released under CC By-SA 4.0! Please feel free to share and adapt the pattern!

Find more patterns at: https://mlemmer.org/free_soft_wear_index/